


ПАНЕЛЬКА ПОД ДОВОДИТЕЛЬНЫЕ ПЕДУ, ВКЛЮЧАЕМОЕ МЕСТО ПОРТА "ПРОГРАММАТОР"



Клавиатура

Промеморис DD13 K155PE3

A3	A2	A1	A0	Q2	Q1	Q0
1	1	1	0	0	0	0
1	1	0	1	0	0	1
1	0	1	1	0	1	1
0	1	1	0	1	0	1

Остальные адреса 1 X X

РАЗЪЕМ ПЕРИФЕРИИ

К1	К2	К3	К4	К5	К6	К7	К8	К9	К10	К11	К12	К13	К14	К15	К16	К17	К18	К19	К20	К21	К22	К23	К24	К25	К26	К27	К28	К29	К30	К31	К32	К33	К34	К35	К36	К37	К38	К39	К40	К41	К42	К43	К44	К45	К46	К47	К48	К49	К50	К51	К52	К53	К54	К55	К56	К57	К58	К59	К60	К61	К62	К63	К64	К65	К66	К67	К68	К69	К70	К71	К72	К73	К74	К75	К76	К77	К78	К79	К80	К81	К82	К83	К84	К85	К86	К87	К88	К89	К90	К91	К92	К93	К94	К95	К96	К97	К98	К99	К100
XS1.10	XS1.11	XS1.12	XS1.13	XS1.14	XS1.15	XS1.16	XS1.17	XS1.18	XS1.19	XS1.20	XS1.21	XS1.22	XS1.23	XS1.24	XS1.25	XS1.26	XS1.27	XS1.28	XS1.29	XS1.30	XS1.31	XS1.32	XS1.33	XS1.34	XS1.35	XS1.36	XS1.37	XS1.38	XS1.39	XS1.40	XS1.41	XS1.42	XS1.43	XS1.44	XS1.45	XS1.46	XS1.47	XS1.48	XS1.49	XS1.50	XS1.51	XS1.52	XS1.53	XS1.54	XS1.55	XS1.56	XS1.57	XS1.58	XS1.59	XS1.60	XS1.61	XS1.62	XS1.63	XS1.64	XS1.65	XS1.66	XS1.67	XS1.68	XS1.69	XS1.70	XS1.71	XS1.72	XS1.73	XS1.74	XS1.75	XS1.76	XS1.77	XS1.78	XS1.79	XS1.80	XS1.81	XS1.82	XS1.83	XS1.84	XS1.85	XS1.86	XS1.87	XS1.88	XS1.89	XS1.90	XS1.91	XS1.92	XS1.93	XS1.94	XS1.95	XS1.96	XS1.97	XS1.98	XS1.99	XS1.100									

- РАЗЪЕМ ПЕРИФЕРИИ
- XP1.4 РЕЗЕРВ
 - XP1.6 СЧИТЫВАНИЕ С МАГНИТОФОНА
 - XP1.8 БРОК
 - XP1.14 ОБЩИЙ
 - XP1.16 +5 ВОЛЬТ
 - XP1.18 +5 ВОЛЬТ
 - XP1.24 +5 ВОЛЬТ
 - XP1.26 ЗАПИСЬ НА МАГНИТОФОН
 - XP1.28 +12 ВОЛЬТ
 - XP1.28 ВИДЕО